

# SPRING GULLY

## STANLEY AVENUE (RECYCLED WATER)






### General Notes for Standpipe Usage


1. Drivers need to ensure they are aware of their vehicle/trailer's legal rated carrying capacity.
2. Vehicles must not leave the site overloaded.
3. When loading tanks ensure that you do not put yourself at risk by climbing in unsafe areas.

### Site Specific Notes

1. If there is no room to park in the yellow queuing area, vehicles need to leave the site and return when there is sufficient room to queue safely.
2. When leaving the site all vehicles will move slowly – drivers need to take extra care in avoiding a collision with approaching traffic.
3. Traffic routing shall be to enter from Spring Gully Road and leave via Retreat Road.  
Vehicles are not to perform a U-Turn in Stanley Avenue in case of an incident.

### Legend

-  Parking Area When Filling
-  Parking Area When Queuing
-  Entry Direction
-  Exit Direction
-  Standpipe Location (Recycled Water)



Disclaimer: This information is provided as a guide only.  
Coliban Water reserves the right to alter or change information. Version B 061211



NORTH